
















PER: FOR:	AXA	BASTA	BKS	CES
	 <p>P289 ▲ 9</p>  <p><b>AX4RP</b></p>	 <p>71 ▲ 3704</p> <p>C . . . . 1-1000</p>  <p><b>BAS5R</b></p> 	 <p>62 ▲ 5</p>  <p><b>BK27</b></p>	 <p>68 ● 5</p>  <p><b>CE129-90 R/6</b></p> <p>BODA - THÖMEE</p>



**1**

PER / FOR	
AXA	(NL)
BASTA	(DK)
BKS	(D)
CES	(D)
DOM	(D)
JUNIE	(D)
PFAFFENHAIN	(D)

PER: FOR:	DOM	JUNIE	PFAFFENHAIN
	 <p>210 ● 5</p>  <p><b>DM141R</b></p>	 <p>11 ▲ 5</p>  <p><b>JU14</b></p>	 <p>1244 ▲ 5</p>  <p><b>PHF15</b></p>

Copyright by Silca S.p.A. 2007





**2**

PER / FOR	
DAEWOO	(ROK)
TRW SIPEEA	(I)
YAMAHA	(J)

PER: FOR:	DAEWOO	TRW SIPEA	YAMAHA
	<p>P406</p> <p>8</p> <p>110</p> <p><b>DWO4REH2</b></p> <p>J.... 1-2000</p>	<p>P427</p> <p>9</p> <p>258</p> <p>W.... 0001-9640</p> <p><b>GT15RDP</b></p>	<p>P406</p> <p>7</p> <p>289</p> <p>A.... 7001-8500 B.... 7001-8000 C.... 7001-8000</p> <p><b>YH35REH2</b></p>


PER:  
FOR:

## HOLDEN (AUS)



MATRIX S - SX - SLX

OPTIONAL



**D731969ZB**

Code device  
Dispositivo a codice  
Code-Vorrichtung  
Dispositif à code  
Dispositivo a código

STANDARD



**D905487ZR**

Tracer point T22  
Tastatore T22  
Taster T22  
Palpeur T22  
Palpador T22



**D705488ZBf**


Cutter F22  
Fresa F22  
Fräser F22  
Fraise F22  
Fresa F22

OPTIONAL



**D909147ZR**

Tracer point T44  
Tastatore T44  
Taster T44  
Palpeur T44  
Palpador T44



**D709148ZB**

Cutter F44  
Fresa F44  
Fräser F44  
Fraise F44  
Fresa F44



**3**

PER / FOR

**HOLDEN**

(AUS)

Copyright by Silca S.p.A. 2007